## **LOOPER**

**LEVEL**: This knob is used to adjust volume of the effect sound, and corresponding effect volume can be adjusted by the knob.

Instructions: Click (bright red) to record mode, click again (bright green) to play the recorded audio, then click to start recording the new audio, then click again to play the recorded audio. Audio (Note: the previously recorded audio will be superimposed on recorded audio during playback);

Double-click in playback mode: pause playback of audio signal (green flashing);

Double-click long-press in playback mode: Delete all

Double-click long-press in playback mode: Delete all recorded audio (the light is off).

**OUTPUT:** Connect your amplifier using a 1/4" phone jack here.

INPUT: Connect your instrument using a 1/4" phone jack here.



Guitar COOLMUSIC Effects Pedal Manual **JAMMER** Looper Weight: 200g (Bare metal). **Dimension:** 115mm(L) \* 66mm(W) \* 35mm(H).

www.coolmusic-tech.com