


LOOPER

A-LP01



LOOPER

LEVEL: This knob is used to adjust volume of the effect sound, and corresponding effect volume can be adjusted by the knob.

Instructions: Click (bright red) to record mode, click again (bright green) to play the recorded audio, then click to start recording the new audio, then click again to play the recorded audio. Audio (Note: the previously recorded audio will be superimposed on recorded audio during playback);

Double-click in playback mode: pause playback of audio signal (green flashing);

Double-click long-press in playback mode: Delete all recorded audio (the light is off).

OUTPUT: Connect your amplifier using a 1/4" phone jack here.

INPUT: Connect your instrument using a 1/4" phone jack here.



Power: 9V DC Center Negative.

Dimension: 115mm(L) * 66mm(W) * 35mm(H).

数字 校音器

A-TN01

TUNER SPECIFICATIONS:

Tuning:12 note equal temperament Detection Range:E0(20.60Hz) to C8 (4186Hz) Tuning Accuracy: ±2 cents

Current Consumption: Max.60mA


CHARACTERISTIC: True Bypass footswitch for crystal-clear tone

* Aluminum-alloy Die Cast case to withstand wear and tear Heavy duty metal footswitch

* Low noise output * Big and bright LED display * Fast detection and high accuracy with good stability .

OUTPUT: Connect your amplifier using a 1/4" phone jack here.

INPUT: Connect your instrument using a 1/4" phone jack here.




AMMER

Guitar COOLMUSIC Effects Pedal Manual LUXURIANT Output Impedance: $1K\Omega$. Output Noise Level: <10mV. Weight: 190g (Bare metal). Power: 9V DC Center Negative.

Dimension: 115mm(L) * 66mm(W) * 35mm(H).

(internal negative external positive) to power the effect This knob is a mode switching knob for delay effects. There are 9 delay effects to -choose from. You can switch different delay effects by turning this knob. FEEDBACK: This knob is used to set the strength of the feedback signal in the delay effect. **DELAY**: This knob is used to set the FEEDBACK intensity of the delay effect in the TIME: This knob is used to set the length of the delay effect in the delay effect. COOLMUSIC® A-DE01 **ECHOLATION** OUTPUT: Connect your amplifier using a 1/4" phone jack here INPUT: Connect your instrument using a 1/4" phone jack here.


POWER: This jack should use a 9V effect adapter





A-RE01

延时



POWER: This jack should use a 9V effect adapter



